


- # STORMWATER BASIN OUTLET NOTES

2. AFTER THE CONTRIBUTING AREAS TO THE POND HAVE BEEN DRAINING DOWN, CONSTRUCTION SHALL BE INITIATED AS FOLLOWS:
 - A. CLEAN BASINS AND OUTLET TRUNCATORS AND REMOVE 6" OF GRAVEL FROM THE TRUNCATOR.
 - B. ADD 18" OF CLEAN, WASHED, #20 CRUSHED STONE AND 6" OF 2" SOLID P.C. S&S PER FEET L.
 - C. REPLACE THE PERFORATED PIPE AND CRUSHED STONE.
 - D. EXTERIORIZE THE FINAL RETENTION IN THE POND.
 - E. FOR TEMPORARY SEDIMENT BASIN TO PERMANENT SEDIMENTATION BASIN.
3. THE 6" OF CRUSHED VERTICAL REBAR SHALL BE CONSTRUCTED AS FOLLOWS:
 - A. REBAR INITIALLY USED AS THE TEMPORARY SEDIMENT BASIN DRAINAGE DRAINAGE. THE REBAR SHALL BE ARMED WITH 1" X 12" STONE. THE TOP OF THE REBAR SHALL BE SET AT THE SAME ELEVATION AS THE BURN AS SHOWN IN THE SLOTTED BURN DRAIN DRAINAGE DRAINAGE.
 - B. WHEN THE PERMANENT BASIN AND REBAR IS CONSTRUCTED, THE PERFORATED PIPE SHALL BE SET AT THE SAME ELEVATION AS AT SLOTTED ELEVATION.

1	6-6-08	REVISED PER FDS	KRM
NO.	DATE	REVISION	BY
			
PROJECT: THE PUTNAM COMMUNITY FOUNDATION SENIOR HOUSING DEVELOPMENT SITUATED: ARLING, TOWN OF CARMEL, NYSALA COUNTY, NEW YORK DRAWING: STORMWATER POND DETAILS			
PROJECT NO.	03196.100	PROJECT MANAGER	J.L.C.
DATE	5-9-07	DRAWN BY	E.M.S.
SCALE	N.T.S.	CHECKED BY	
		DRAWING NO.	SHEET
		D-5	1/3
			14